

PLEASE NOTE

This document <u>may have been updated</u> with new information, changes, and corrections.

Be sure to visit my presentation web site and download the latest version of this document. It could make an important difference to your work!

http://aviation.derosaweb.net/presentations

Thank you, John



Many modern glider Instruments have control knobs which are used to change settings.

However, with our panel's closely spaced instruments there are times when the knob is difficult to get to and manipulate.

Or our arms may just be too short to conveniently reach the knobs while bouncing along in a thermal.

WHAT TO DO?








I have seen some pilots placing clear tubing onto their instrument's control knobs.

That works OK but its ugly, flimsy and, even worse, prone to falling off at inopportune moments.



How about making nice rigid metal extensions for those problematic knobs?

Let's get started!







Drill motor (press)

Drill bit

File

Hack Saw

Allen wrench set

Threading tap & wrench

Calipers

Blue thread locker













Step 2 – Gather the following items

All items are available on Amazon

Drill bit that matches the instrument's extension rod's diameter.


Extension rod material that matches the instrument's control shaft size. See a following slide to determine the diameter needed.

Small <u>set screw</u>. (6-32 or M3 screw)

Aluminum <u>extension barrel blank</u> material (3/8" or 9mm dia).
See a following slide to determine the length required.



Machine threading <u>Tap</u> matching the <u>set screw</u>. (6-32 or M3)



Step 3 – Measure the size of the instrument's control shaft

3a) Remove the knob by loosing the set screw found underneath the knob's cap.



3b) Measure the instrument control shaft's diameter using a caliper. A ruler is not accurate.



NOTE: Many instrument control shaft's diameter is 3mm while some are 5/32" (~4mm).

3c) Purchase steel rod material of the same diameter.
Stainless steel rod is best.



Step 4 – Cut an extension barrel blank

4a) Cut a piece of the extension barrel material to the needed height based on your instruments.

4b) Smooth the edges of the extension barrel with a file.

4c) Hint: Cut some extra rod barrels. The next steps can cause mistakes so you might need a few more!





Extension barrel with an instrument control shaft hole drilled through.

Step 5 – Drill a hole thru the extension barrel blank

5a) Drill* a hole all the way through the middle of the extension barrel blank. The drill bit size must match the instrument's control shaft size as measured in a previous slide.

5b) Confirm that the extension rod fits snuggly onto the instrument's control shaft and is of the correct length.



*Hint: Using a drill press and drill press vise is recommended.


If you have access to a lathe to drill the hole this will be more accurate.

Step 6 – Drill and tap a hole for the set screw

6a) Drill a hole for the set screw. The hole should be rather close to one end of the extension barrel.

6-32 set screw uses a #36 drill bit M3 set screw uses a 3mm drill bit

6b) Tap the hole with the appropriate tap size and handle.





Step 7 – Cut a piece of extension rod

7a) Cut a piece of the extension rod material about 1/2" or 13mm longer than the extension barrel blank.

7b) This rod will be trimmed to the proper length in the following steps.

7c) File smooth the edges of the extension rod





Step 8 – Assemble the pieces onto the instrument's control shaft

8a) Assemble the knob extension components together (extension rod, extension barrel, and instrument knob).

8b) Place the assembly onto the instrument's control shaft and tighten the extension barrel's set screw.





Step 9 – Trim the Extension Rod

9a) Place the knob onto the top of the extension rod. There will be a gap between the knob and extension barrel.

9b) Trim the extension rod to the appropriate length so that the bottom of the knob is against the top of the extension barrel.



Step 10 – Preparing for gluing the extension rod into the extension barrel



10a) Place the knob onto the extension rod and tighten the knob's set screw under the cap.



10b) Remove the knob + extension rod from the extension barrel.



10c) Remove the extension barrel from the instrument's control shaft. This important step will protect the instrument during the next step.



Step 11 – Gluing the extension rod into the extension barrel

<u>WARNING</u> – Be <u>very careful</u> to <u>NEVER</u> get any thread locker onto the instrument's control shaft or inside the instrument itself!

11a) Put a <u>very small amount</u> of <u>BLUE</u> thread locker onto the extension rod as shown at right.

11b) Using a twisting motion insert the knob/extension rod back into the extension barrel.

11c) Wipe off any excess thread locker from the assembly and let dry for ~2 hours.








Step 12 – Painting of the Assembly

12a) Remove the knob from the extension assembly.

12b) Paint the extension barrel flat-black.





Step 13 – Final Assembly

13a) Replace the original instrument's knob onto the assembly's extension rod, tighten the knob's set screw, and then replace the knob's cap.

13b) Tighten the set screw on the extension barrel.

13c) VERIFY that required instrument knob rotation and push travel is working properly!

Adjust the extension barrel's set screw as required.



Your work is done! Congratulations! It looks great!

See My Other Presentations

- Glider Electrical Wiring
- Transceiver Troubleshooting
- Oxygen Systems
- Working with Glider Air Lines
- Trailer Wiring & LED Lighting
- Trailer Chains
- Soaring Pilot Relief Systems
- Battery Testing
- Emergency Location Devices
- Survival Kits

- Spar Alignment Tool
- L'Hotellier Fittings
- Carbon Fiber Panels
- IGC Filename Decoding
- Blanik L-23 Strut Work
- Removing Painted Lettering
- Open Glider Network
- Instrument Knob Extensions
- Landing Gear Warning Systems

http://aviation.derosaweb.net/presentations

Let me know of any comments!